

Overlay Instructions

Congratulations on acquiring your set of new 5-piece acrylic emblem overlays!

Listed below are a detailed set of instructions to help you install your overlays correctly.

****You MUST watch the YouTube videos in the link below, then read the instructions all the way through BEFORE attempting to install****

*** www.isfpcustomemblems.com/video-archive ***

Click on **5-piece**, then watch the **3-piece** method. The 3-piece video is a shorter video with less info, meant to be watched **after** the 5-piece video.

NOTE – We No Longer Use All-Sol as this tape **cannot** be repositioned, we recommend doing a *test run* before removing the plastic backing off the ovals to help you feel more confident in your installation!

*** MUST install in Warm Weather (Minimum of 10° Celsius / 50° Fahrenheit) and on a CLEAN and DRY Vehicle***



Tools needed: Xacto knife/Sharp knife, and/or Tweezers, Multi-Surface cleaner (Windex, Mr.Clean, Lysol etc.), (1) Micro-fiber cloth, (2) 3M Primer 94 Pens (included) *Wash hands before/after installation.

****Before you remove the plastic backing on the ovals, do a test run first to see how to install****

Step 1: Ensure your vehicle is clean. Take a clean micro-fiber cloth and spray your vehicle's emblem with the selected multi-surface cleaner of choice, and wipe it clean with the cloth; ensuring to remove any dirt, or debris from the emblem. *Let dry for 10-20 seconds.*

Step 2: Gather your materials and ensure you have **EVERYTHING** needed to continue with the next steps!
(Exacto knife, 3M Primer Pens, Music, Coffee, and whatever else you may need!)

******You should have watched the installation video already, but if not, watch before moving on******

Step 3: Use your *3M Primer Pen*, pinching the middle where the black dot is to activate, and cover your vehicles ENTIRE emblem, while focusing on the outer ring. (This ensures proper bonding for the overlay). Once the emblem is fully covered move onto the next step.

Step 6: Remove the plastic backing on the Oval using your xacto knife, or tweezers. (The piece the lettering sits in) then, place either the left, or right corner onto the Ford emblem mounted on the vehicle, carefully aligning the top section of the overlay with the top section of the emblem. (***Please note this CANNOT be repositioned once applied, before removing the red backing, do a trial install so get comfortable with the process and the placement before you attempt to install***) Run your finger along the top of the emblem while pressing down lightly to ensure bondage with the emblem. Go to the other side and check to make sure both corners line up and are equal.

Step 7: Take your xacto knife/tweezers and remove the plastic backing to the (F). Place it in the (F) spot for the overlay on the truck, pressing firmly on all parts of the letter and **paying extra attention to the top, bottom, and edges of the letter as pictured below**. Then remove the plastic backing for (ORD) and do the same, pushing firmly, and evenly across the all of the letters to ensure proper bonding as pictured below. (*Doing this will guarantee the letters stick to the emblem without chance of lifting around the edges*)



Step 8: Remove the plastic backing to the inner ring and place it over the inner ring section.

Step 9: Take the plastic backing off the outer ring and place it on the outer ring section of the emblem. Take your hand and push all around the emblem to make sure it is pushed on and has starting the bonding process! To guarantee bonding process, *Do Not wash your vehicle for a full 24 hours* from the date, and time of installation; doing so will void warranty.

Step 10: Enjoy those stares, share the love and ask about our referral program to earn yourself some cash!

*****DO NOT wash your vehicle for a Full 24 hours*****

If you have any questions, concerns, or comments, please reach out to us at isfpquestions@gmail.com or message us on *Instagram* at: [@isfpcustomemblems](https://www.instagram.com/isfpcustomemblems) or by visiting our website at www.isfpcustomemblems.com and leaving a message through the chat option and we'll get back to you asap!

CARE INSTRUCTIONS

- Wash your emblem as you would the rest of your vehicle, holding the pressure washing wand at the recommended 1.5 – 2 ft away from your vehicle.
- *DO NOT* hold the pressure washer directly on the overlay for a prolonged period as like any other part of your vehicle, such pressure could cause damage. (Recommended time no longer than 2 seconds)
- *DO NOT* wipe your emblems with a cloth unless the cloth is around your fingertip and you are **CAREFULLY** going around the letters as they could pull up. (especially with chrome lettering)
- When/If you wish to remove your overlay, please go to the video archives section of the website and watch our removal video. You can also contact us to provide a printable version of these instructions.